

Schema sostituzione stecca per Palladio Standard

Rib replacement - parasol Palladio Standard

Strebenersatz - Schirm Palladio Standard

Togliere la copertura dell'ombrellone svitando dadi fine stecca e finale punta superiore.

Take off the fabric cover by unscrewing the nuts at the end of the ribs and put away the wooden top.

Schraubenmuttern, die am Ende der Streben befestigt sind abschrauben, Holzspitze abnehmen und den Stoffbezug abmontieren.



Con un cacciavite e un martello rompere la punta inferiore della stecca da sostituire come mostrato in foto.

Break the lower end part of the broken rib with a screwdriver and a hammer as shown in the picture.

Anhand eines Schraubenziehers und eines Hammers wird das untere Endteil des Streben gemaess Abbildung gebrochen.



Con poco sforzo la stecca si romperà aprendosi in 2 parti.

Without effort the rib will break into 2 parts.

Die Strebe bricht mühelos in zwei Haelften.





Risultato finale.

Final result.

Endergebnis.

Ora è possibile usare nuovamente l'ombrellone.

Now the parasol can be employed again.

Nun kann der Schirm wieder verwendet werden.

